





Technical information  
Explosion drawing and parts list

EB25 (6300000) EB25 EDGEBANDER | TRIMMING UNIT | Version A

Pos.	Serial No.	Code	Description	Quantity
1		6307031	FRONT TRIM UNIT BASE	1
2		1610018	BUSHING KH 1228	3
3		1628072	SPRING CAP	2
4		1626045	SPRING	1
5		1688015	RETAINING RING D.12	1
6		1628089	GUIDE ROD	1
7		1675031	HEX. SOCKET SET SCREW M.6X10	2
8		1606056	MAGNET HOLDER	1
9		1626042	SPRING	1
10		3870033	PAN HD. TAPPING SCREW 4X5/8 PH.B.	2
11		4445030	MICROSWITCH	1
12		1628074	BOLT	1
13		1383003	WASHER AET D.6.4	4
14		1675035	HEX. SOCKET HD. CAP SCREW M.6X10	4
15		1650049	MAGNET ASS'Y 220V	1
16		3885004	SELF-LOCKING HEX. NUT M.8	5
17		6331016	MOVABLE BLADE	1
18		1628071	PIVOT SCREW	1
19		1673018	HEX. SOCKET FLAT HD. SCREW M.6X20	2
20		1631005	FIXED BLADE	1
21		1322078	LOCK NUT	2
22		1650050	CORD ASS'Y FOR FRONT TRIMMING STATION	1
23		2385005	HEX. NUT M.4	1
24		9580005	WASHER D.10.2X20X0.26	1
25		4473021	FLAT HD. SCREW M.8X35	4
26		2023036	WASHER D.8.25X15.75X2	4
27		4434029	MICROSWITCH HOLDER	1
28		1372016	PAN HD. SCREW M.4X6 PH.	2
29		4428042	GUIDE ROD	1
30		1680026	WASHER D.4.3X9X0.8	2
31		6371025	HEX HD. SCREW M.4X12	1
32		8523386	BLADE COVER PROTECTION	1
33		5284002	ARANLOCK D.4	2
34		8519325	WARNING LABEL	1
35		8522367	PROTECTOR SHAFT	1
36		8523385	BLADE HOLDER PROTECTOR	1
37		8423195	WASHER D.6.3XD.15X1.5	1
38		1675045	HEX. SOCKET HD. CAP SCREW M.6X15	1
39		6478001	SCREW M.4X8 PH.	1